



S12i



Portable Bluetooth Speaker

USER GUIDE

Familiar with your Bluetooth speaker

Prior to use the Bluetooth Speaker, please fully charged the speaker and paired&connected with your Bluetooth devices.

1. Power Switch/Mode Switch
2. Micro USB Socket
3. Micro TF card socket
4. AUX in Port
5. Speaker
6. LED Indicator
7. Next Track/Volume Up +
8. Multifunction Button (MFB) for Bluetooth Pairing, Pause/Play, Answer, Hang up
9. Previous Track/Volume Down -
10. Microphone



Overall Schematic

Features

- Bluetooth Music Playing
- Two-way conversation
- High quality aluminum alloy
- Silicone non-slip pad
- Voice Prompts Call ID prompt
- MP3/WMA/WAV music play
- Top grade NdFeB speaker

Use Instructions

Charging

1. While the speaker is being charged, the LED indicator will keep red. Once the speaker is fully charged, the led turns blue. Usually it takes 2 hours. (Support use while charging)
2. When the speaker is in low power, charge it through the PC, DC Adapter, Car Charger and the Micro USB cable&Connector attached.

Turn On Your Speaker

In off status, press the power switch  for 3 seconds to turn it on with "Power on" voice prompt. It will enter pairing mode automatically

with “Pairing” prompt and green and blue indicator will blink alternately. Pair it with your Mobile Phone and Pad.

1. Turn on the Bluetooth function of your mobile;
2. Search for new Bluetooth devices named “S12i” model.
3. Choose the S12i and press “OK” to connect. For the smart mobile phone, click the model S 12i to connect automatically. “0000” is the PIN code if needed by some mobiles.
4. After successfully connected, you will hear “Connected” and blue indicator blinking slowly.

Note: It is needed to connect the Bluetooth devices again manually if the Bluetooth version is 2.1 or above, it will connect automatically. To switch modes among the Bluetooth mode, MP3 mode and Line-in mode(Green lights keeps on), just click the power switch button to switch the mode, The mode switch should be operated after the mode indicator shut down, otherwise it won't work.

Note: 1. This speaker has automatic identification mode, if there is no audio cable or TF card inserted, it won't be able to switch to the corresponding mode.

2. Insert TF card, the speaker will enter music mode automatically. Insert AUX audio cable, it will enter Line- in mode.
3. Music mode means TF card mode, play the music in the TF card. Line-in mode means audio cable inserted to play music from external devices.

Use your speaker

Answer the call

—When call comes, click the MFB to answer it.

End the call

—During the call, click the MFB to end it.

Call mute

—During the call, double click the MFB in 1s to make the call mute. (Repeat to return)

Reject the call

—When call comes, double click the MFB in 1s to reject it.

Redial the call

—In on status and connected with mobile phone via Bluetooth, double click the MFB to redial the last call you dialed.

Play/Pause

—While playing music, click the MFB button to pause it, repeat to play again.

Previous track

—During the music, double click the VOL “-” button to play the previous song.

Next track

—During the music, double click the VOL “+” button to play the next song.

Adjust the volume

—Click or long press the VOL “+” key to increase the volume, or VOL “-” to decrease the volume.

In Bluetooth mode, indicator will blink quickly the volume reach the MAX or MIN after the volume reach the MAX or MIN, the status While in MP3/Line-in Mode, there is no voice prompt when it reach MAX or MIN status.

Warm Prompt: Adjust the volume appropriately to avoid damage to your hearing.

Power level prompt: The working time depends on the music style, normally 4-8 hours. Under Bluetooth mode, press the volume key “+” & “-” simultaneously to get battery level voice prompt of “Battery High”, “Battery Middle” and “Battery Low” .

Power and Charging

Power applicable: Working voltage of lithium battery:

3.7V-4.2V/500 mAh. DC 5V charging power or power from computer USB output.

Charging methods: Use the Micro USB cable to connect the speaker with the computer USB port or DC 5V charger. The indicator will be red while charging. Once the speaker is fully charged, The led turns blue.

Safely Information

Check local laws regarding the use of mobile phones and speakers while driving. If you use the speaker while driving, ensure your attention and focus remains on the road and you drive in a

responsible and safe manner. Never allow children playing with the speaker small parts may be a choking hazard. Observe all signs that require an electrical device or RF radio product to be switched off in designated areas. (These could include hospitals, blasting areas, and potentially explosive environments.) Turn off your speaker prior to boarding an aircraft. Do not use your speaker in an aircraft. Never mount or store your speaker over any air bag development area as serious injury may result when the air bag deploys. Do not open or mutilate the built-in battery. Dispose of batteries according to local regulations. Do not dispose as household waste.

Maintenance

- Turn your speaker off before placing it in your pocket or bag to avoid the MBF button is accidentally touched.
- Do not expose the speaker to liquid or moisture environment as it is not waterproof.
- Do not use abrasive cleaning solvents to clean the speaker.
- Do not expose the speaker to extreme temperature conditions. The best store temperature range is from -10 to +60, otherwise the life of the speaker will be influenced.
- Do not dispose of the speaker in a fire as it this may result in an explosion.
- Do not bring your speaker into contact with sharp objects as this will cause scratched and damage.
- Do not attempt to disassemble the speaker as it dose not contain serviceable components.

Parts List

- | | |
|---------------------------|-------------------------------|
| 1, Speaker -----1 pcs | 2, User Guide-----1 pcs |
| 3, AUX in Cable-----1 pcs | 4, USB charging cable----1pcs |

Specification:

Model: S12i	S/N ratio: 80dB
Speaker size: 1.5inch	Distortion: <3%
Output Power: 3W	N.W.: 254g
Frequency: 80Hz-20KHz	MEA: W62*H70*D62mm



www.oricore.com